

Remote Monitoring for Business

Quick Start Guide - ALTA Ethernet Gateway 4

1




Use the QR code above to download the iMonnit app. Or, go to [iMonnit.com](https://imonnit.com) to create an account.

2



Follow the in-app instructions to add devices to your account. When prompted, select the desired **Reliability Settings**.

3



Connect the antenna and Ethernet cord. Then attach the power cord to your [Ethernet Gateway 4](#). All lights should turn green.

4



iMonnit is the easy way to view your sensor data and customize your sensor settings in the app or online at imonnit.com.

For more detailed instructions, documentation, how-to guides and video demonstrations on using Monnit Wireless Sensors, Wireless Gateways, and iMonnit Software, visit our support page at monnit.com/support/.



Monnit Corporation

3400 South West Temple • Salt Lake City, UT 84115 • 801-561-5555
www.monnit.com

Change Log

Date	Change	Reason	Modified By
3/22/21	Change Log Created	Manager Request	
12/4/23	Removed App Store and Google Play		D. Hill