



Remote Monitoring for Business



Getting Started
with PoE•X Sensors

I. INTRODUCTION

This guide is specific to the differences of working with PoE•X sensor line. Before reading this you should be familiar with using the [Mine SDK](#) with ALTA Sensors and gateways. For more information please see the Mine User Guide.

When programming for a PoE•X device in Mine, you'll have to manage both a sensor object and a gateway object. To facilitate using the same sensor configuration parameters as other Monnit Sensors and standard gateway configurations as other Monnit gateways and PoE•X sensors internally utilize two unique identifiers and functions segregated and referred to as SensorID and functions as well as GatewayID and functions. There is not a separate gateway device needed, all functions for both objects are contained within the single device. To accommodate these functions and configuration capabilities of the device the implementation of the device in Mine will require managing both objects in code. The separation can be hidden from the end user if you choose to do so.

REGISTRATION

In order to properly register a PoE•X device to Mine, you'll have to follow these steps:

1. Go to <https://www.imonnit.com/DeviceInfo> and enter your PoE•X device identifier into the form.
2. This interface will recognize the device as a PoE•X device and it will return both Sensor and Gateway object information.

Note: The information retrieved manually through the Device Info page is also available programatically with JSON or XML through the following Rest API's: (<https://www.imonnit.com/api>)

- **SensorLookup**
- **GatewayLookup**
- **WifiGatewayLookup** (This is an undocumented API with the same parameters as SensorLookup, and the same result object as gatewaylookup. Originally used with our WiFi line of sensors, it is now also needed for our PoE•X line as well).

3. Use that Gateway information to create your Gateway object into the Mine server.
4. Having created your Gateway object, you will now be able to register your PoE•X Sensor to it.
5. With the Sensor information provided from the DeviceInfo form, you'll be able to create a Sensor object as well.
6. Register the Sensor to the Gateway object using the gateway you already registered.
 - PoE•X device is now ready to talk to Mine, once you point the device to your Mine Server.
7. Configure your PoE•X device to point to your application ID address by visiting <https://www.imonnit.com/setHost>.
 - Your PoE•X device will need to be unlocked in order to change the default server host from the iMonnit Platform.

II. ACTIONS AVAILABLE

When wanting to update configurations to your PoE•X device you'll have to utilize both Gateway and Sensor objects.

Most configuration updates will be implemented through the Sensor object. The sensor object will share the configuration by type with other Monnit sensor lines (ALTA/Gen1) which are also PoE ready. Allowing you to re-use code written between different sensor lines

The other configurations will be changed through the Gateway object. In particular when you're wanting to set a static IP address for the device, or change the host IP Address that the device communicates with. Also enabling data interfaces (Modbus/SNMP) can be done through the gateway object.

The methods for updating these configurations for the PoE•X are shared with the ALTA EGW4 Ethernet Gateway. Also allowing you to re-use the code you write here to easily use other sensor lines as needed.

SUPPORT

For technical support and troubleshooting tips please visit our support library online at monnit.com/support/. If you are unable to solve your issue using our online support, email Monnit support at support@monnit.com with your contact information and a description of the problem, and a support representative will call you within one business day.

For error reporting, please email a full description of the error to support@monnit.com.

WARRANTY INFORMATION

(a) Monnit warrants that Monnit-branded products (Products) will be free from defects in materials and workmanship for a period of one (1) year from the date of delivery with respect to hardware and will materially conform to their published specifications for a period of one (1) year with respect to software. Monnit may resell sensors manufactured by other entities and are subject to their individual warranties; Monnit will not enhance or extend those warranties. Monnit does not warrant that the software or any portion thereof is error free. Monnit will have no warranty obligation with respect to Products subjected to abuse, misuse, negligence or accident. If any software or firmware incorporated in any Product fails to conform to the warranty set forth in this Section, Monnit shall provide a bug fix or software patch correcting such non-conformance within a reasonable period after Monnit receives from Customer (i) notice of such non-conformance, and (ii) sufficient information regarding such non-conformance so as to permit Monnit to create such bug fix or software patch. If any hardware component of any Product fails to conform to the warranty in this Section, Monnit shall, at its option, refund the purchase price less any discounts, or repair or replace nonconforming Products with conforming Products or Products having substantially identical form, fit, and function and deliver the repaired or replacement Product to a carrier for land shipment to customer within a reasonable period after Monnit receives from Customer (i) notice of such non-conformance, and (ii) the non-conforming Product provided; however, if, in its opinion, Monnit cannot repair or replace on commercially reasonable terms it may choose to refund the purchase price. Repair parts and replacement Products may be reconditioned or new. All replacement Products and parts become the property of Monnit. Repaired or replacement Products shall be subject to the warranty, if any remains, originally applicable to the product repaired or replaced. Customer must obtain from Monnit a Return Material Authorization Number (RMA) prior to returning any Products to Monnit. Products returned under this Warranty must be unmodified.

Customer may return all Products for repair or replacement due to defects in original materials and workmanship if Monnit is notified within one year of customer's receipt of the product. Monnit reserves the right to repair or replace Products at its own and complete discretion. Customer must obtain from Monnit a Return Material Authorization Number (RMA) prior to returning any Products to Monnit.

Products returned under this Warranty must be unmodified and in original packaging. Monnit reserves the right to refuse warranty repairs or replacements for any Products that are damaged or not in original form. For Products outside the one year warranty period repair services are available at Monnit at standard labor rates for a period of one year from the Customer's original date of receipt.

(b) As a condition to Monnit's obligations under the immediately preceding paragraphs, Customer shall return Products to be examined and replaced to Monnit's facilities, in shipping cartons which clearly display a valid RMA number provided by Monnit. Customer acknowledges that replacement Products may be repaired, refurbished or tested and found to be complying. Customer shall bear the risk of loss for such return shipment and shall bear all shipping costs. Monnit shall deliver replacements for Products determined by Monnit to be properly returned, shall bear the risk of loss and such costs of shipment of repaired Products or replacements, and shall credit Customer's reasonable costs of shipping such returned Products against future purchases.

(c) Monnit's sole obligation under the warranty described or set forth here shall be to repair or replace non-conforming products as set forth in the immediately preceding paragraph, or to refund the documented purchase price for non-conforming Products to Customer. Monnit's warranty obligations shall run solely to Customer, and Monnit shall have no obligation to customers of Customer or other users of the Products.

Limitation of Warranty and Remedies

THE WARRANTY SET FORTH HEREIN IS THE ONLY WARRANTY APPLICABLE TO PRODUCTS PURCHASED BY CUSTOMER. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED. MONNIT'S LIABILITY WHETHER IN CONTRACT, IN TORT, UNDER ANY WARRANTY, IN NEGLIGENCE OR OTHERWISE SHALL NOT EXCEED THE PURCHASE PRICE PAID BY CUSTOMER FOR THE PRODUCT. UNDER NO CIRCUMSTANCES SHALL MONNIT BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES. THE PRICE STATED FOR THE PRODUCTS IS A CONSIDERATION IN LIMITING MONNIT'S LIABILITY. NO ACTION, REGARDLESS OF FORM, ARISING OUT OF THIS AGREEMENT MAY BE BROUGHT BY CUSTOMER MORE THAN ONE YEAR AFTER THE CAUSE OF ACTION HAS ACCRUED.

IN ADDITION TO THE WARRANTIES DISCLAIMED ABOVE, MONNIT SPECIFICALLY DISCLAIMS ANY AND ALL LIABILITY AND WARRANTIES, IMPLIED OR EXPRESSED, FOR USES REQUIRING FAIL-SAFE PERFORMANCE IN WHICH FAILURE OF A PRODUCT COULD LEAD TO DEATH, SERIOUS PERSONAL INJURY, OR SEVERE PHYSICAL OR ENVIRONMENTAL DAMAGE SUCH AS, BUT NOT LIMITED TO, LIFE SUPPORT OR MEDICAL DEVICES OR NUCLEAR APPLICATIONS. PRODUCTS ARE NOT DESIGNED FOR AND SHOULD NOT BE USED IN ANY OF THESE APPLICATIONS.



Monnit Corporation

3400 South West Temple • Salt Lake City, UT 84115 • 801-561-5555
www.monnit.com

Monnit, iMonnit and all other trademarks are property of Monnit, Corp. © 2020 Monnit Corp. All Rights Reserved.